

PORT LATENCY

To ensure proper communication between your Motoza cable and your PC, port latency may need to be adjusted. To check this setting:

- ◆ Connect the Motoza USB cable to your computer.
- ◆ The cable does not need to be connected to the OBD-II port in your vehicle.
- ◆ Open Device Manager.
- ◆ Expand “Ports,” right click the USB Serial Port, and select “Properties.”
- ◆ Click on the “Port Settings” Tab.
- ◆ Click the “Advanced” button.
- ◆ Verify that the Latency Timer is set to 1msec. If not, select 1msec and click “OK.”

